



RELEASED
2/2/22

PPP

Part Number	K10112	Box Part Number	N/A	Dimension	N/A
Description	Saddle for D206-642-112/-114	Other Packaging			
		Logo Decals			

Packaging Instructions and Decal Placement

K10112

Place kit in D206-642-112/-114 box. Place some more foam on top to prevent movement.
Add hardware and saddle. Seal box and apply label D2729-3 as per instructions in QSI 014.

Note: Fill all voids of box with foam to prevent movement.

D2729-4

D2729-3

N/A



Dart Aerospace Ltd.
1270 Aberdeen Street
Hawkesbury, ON K6A 1K7
CANADA
TEL.: 1 613 632-5200

K10112 SADDLE

CHG003

INCLUDE PARTS FOR:

D206-642-112

CHG009

D206-642-114

CHG004

B/N: BXXXXXX

Revision: H

Date: 16.02.10

Handwritten signature and date 16.02.10